
THESE WIRES CONNECT THE OEM IGNITION POWER FOR THE MCNEILUS CONTROL SYSTEM
FUSE OR DISCONNECT SWITCH SUPPLIED BY MCNEILUS OR CHASSIS OEM FOR SYSTEM PROTECTION.
MAIN POWER FROM OEM IGNITION SOURCE
HEAT SHRINK END OF WIRES
SPARE POWER WIRES
PENDANT BOARD
DRUM S/S
DRUM C/D
CHUTE U/D
HOPPER
BM STOP
TAG
PUSHER
WORK LT
DISCHARGE
CHUTE UP
CHUTE DOWN
CHUTE LOCK
CONSTANT SPEED
HOPPER UP SIGN
BM ACTIVATE
BM U/D
DRUM COUNTER
OIL TEMP